



# APTEK LABORATORIES, INC.

ISO 9001 / AS9100 Certified

28570 Livingston Avenue, Valencia, CA 91355-4171 • (661) 257-1677 FAX (661) 257-8939

## TECHNICAL DATA & INFORMATION

### DIS-A-PASTE® 2310HTC-PMF

Premixed-frozen, highly thermally conductive (HTC), low modulus adhesive

### PRODUCT DESCRIPTION

**DIS-A-PASTE 2310HTC-PMF** was developed to be a closely-related analog of DIS-A-PASTE 2310-PMF, displaying higher thermal conductivity and lower CTE values, without loss of the desired characteristics of the standard product, such as low modulus, low Tg, low outgassing, electrical insulation, and excellent adhesion to dissimilar substrates. Aptek has developed a unique, proprietary blend of thermally conductive fillers and has optimized filler loading to drastically increase thermal conductivity over the standard product while maintaining good handling properties and substrate wetting.

### KEY FEATURES AND BENEFITS

- More than twice the thermal conductivity compared to standard DIS-A-PASTE 2310-PMF (1.8 W/mK vs. 0.8 W/mK).
- **DIS-A-PASTE 2310HTC-PMF** provides a more effective heat-sink and therefore cooler interface temperatures under heat generating devices/components.
- New style rigid tapered tip included with product for easy dispensing of this highly-filled system
- Low Tg (<-60°C) for excellent low temperature cycling and performance with minimal stress
- Excellent substrate adhesion; superior to silicones: no primer required
- Also available with various thicknesses of internal bondline spacers upon request

### HANDLING INFORMATION

1. Work life @ 25°C in 3cc syringe after thaw: >4 hrs
2. **DIS-A-PASTE 2310HTC-PMF** syringes are shipped in dry ice. Upon receipt, transfer frozen syringes to a storage freezer @-40°C or below.
3. To thaw, remove syringe from freezer and allow to warm to room temperature. Do not place in oven or microwave as this will shorten use life.
4. Typical thaw time for 3cc syringe @ 25°C or ambient temperature is approximately 10-15 minutes.
5. Extrusion rate, gm/min @ 25°C and 65psi:
  - a. With 16 gauge rigid tapered tip (RTT): 1.8 -- This is the recommended tip to maximize flow characteristics and minimize back-pressure for easy dispensing
  - b. With 15 gauge, ½" long metal tip: 0.6

#### - DISCLAIMER NOTICE -

All statements, technical data, and recommendations expressed herein are based on tests believed to be reliable and accurate. However, APTEK LABORATORIES, INC. gives no warranty, expressed or implied, regarding the accuracy of this information. It is intended that the buyer and user of these products shall determine the suitability of the information provided for his specific application, and is responsible for its selection.

APTEK LABORATORIES, INC. shall not be liable for any injury, loss or damage, direct or consequential, arising out of the use or misuse of these products, or of the information given in these data bulletins. Purchasers assume all risk and liability whatsoever in connection with the use of these products and this information.

**CURE SCHEDULE**

(when cured in an air-circulating oven)

4 hours @ 85°C  
 -or-  
 2 hours @ 100°C  
 -or-  
 1.5 hours @ 125°C  
 -or-  
 1 hour @ 150°C

## Notes:

1. These schedules are conservative and should be used as guidelines. Achievement of the application requirements/properties should be the determining factor in the selection of cure schedule.
2. The above cure schedules were determined by the achievement of specific physical property values i.e. optimum lap shear strength for adhesive applications and ultimate hardness for encapsulant/potting applications.

**TYPICAL PROPERTIES**

(Values not to be used for specification purposes)

<b><u>CHARACTERISTICS</u></b>	<b><u>DIS-A-PASTE 2310HTC-PMF</u></b>	<b><u>TEST METHOD</u></b>
Color	Light gray/tan	Visual
Specific gravity	1.8	ASTM D-1475
Viscosity/consistency @ 25°C	Smooth thixotropic paste	Visual
Flash point, °C	>200	ASTM D-92
Shelf life @-40°C or below, months factory sealed, pre-mixed frozen-syringes	6	
<b><u>CURED PHYSICAL PROPERTIES</u></b>	<b><u>DIS-A-PASTE 2310HTC-PMF</u></b>	<b><u>TEST METHOD</u></b>
Hardness, Durometer A	93	ASTM D-2240
Lap shear, @25°C, Al to Al, psi	450	ASTM D-1002
Glass transition temp., °C	-65	ASTM E-831
Thermal coefficient of expansion, in/in/C	22 x 10 <sup>-6</sup> 152 x 10 <sup>-6</sup>	ASTM E-831 ASTM E-831
Thermal conductivity, @25°C, W/m°K	1.8	ASTM C518-04
Outgassing @10 <sup>-6</sup> Torr		
TML, %	0.65	ASTM E-595
CVCM	0.02	ASTM E-595

<u>CURED ELECTRICAL PROPERTIES</u>	<u>DIS-A-PASTE 2310HTC-PMF</u>	<u>TEST METHOD</u>
Volume resistivity @25°C, ohm-cm	2.1 x 10 <sup>14</sup>	ASTM D-257
Dissipation factor (D)/ Dielectric constant (K) @25°C, 1 MHz	0.010/4.83	ASTM D-150
Dielectric strength, 0.067" thick, volts/mil	530	ASTM D-149

#### SAFETY AND FIRST AID

**DIS-A-PASTE 2310HTC-PMF** is a mineral-filled hybrid polymer blend which is safe to handle as it is packaged in sealed syringes. There should be no need to touch the adhesive. Avoid contact with skin and eyes and use in a well-ventilated area. In case of eye contact, flush with fresh clean water for at least 15 minutes; for skin contact, wash thoroughly with soap and water. If ingested, drink at least one pint of water and call a physician. Refer to Material Safety Data Sheet for more details.

Revised: 04/17/23-mjv

Issued: 09/27/16

**APTEK®** is a registered trademark of Aptek Laboratories, Inc.

**DIS-A-PASTE®** is a registered trademark of Aptek Laboratories, Inc.