



## Announcement

Effective September 1, 2009, Aptek Laboratories, Inc. will change the dual cartridge packaging of its specialty adhesives to a new, improved style cartridge.

The newly-designed dual cartridge, which Aptek Laboratories, Inc. will convert to, clearly offers advantages over the old-style cartridge. This new cartridge is more durable and withstands the higher back pressure of highly filled resin systems. It also has a positive connecting interface which firmly seats and interlocks between the cartridge and the mixing tip. Furthermore, the improved mixing tip design allows for it to lock on securely to the cartridge's exit port to prevent air ingress during operation, thus greatly minimizing the chance of air voids in the dispensed adhesive.

This positive interface also permits the user to remove and discard the mixing tip which prevents any cross-contamination of the A side with the B side, allowing the user to recap the cartridge and use it with a new mixing tip at a later time.

Another advantage of the new cartridge system is the availability of a Luer Lock adaptor for the end of the mixing tubes. This allows the user to attach a needle tip to dispense smaller amounts of product and permits the product to be applied in tight spaces, where in the past, a syringe was necessary.



Aptek's Technical Service Department will be available to answer any questions or comments that you may have about this new cartridge system.